

WORK MANUAL



1. Remove the ADVA SPS Smart System from the transport packaging.
2. Straighten the ADVA SPS Smart System so that it is firmly on all four wheels.
3. Place the system to the location of use.
4. Fix the wheel brakes so that they do not move freely.
5. Use the key to open the disinfectant container that is located at the bottom of the system.
6. Remove the two empty five litre tabs placed in the system. Unpack them and open the caps. Do not throw away the caps. The two tabs are the same. We will call them first and second tabs.
7. Pour the liquid disinfectant you will use into the first tab. It is important to know that the system only works with liquid disinfectant. Any consistency other than liquid will clog the pump. Put the tab back in the container. There is a slot on the front panel of the system through which the level of the disinfectant can be monitored. Place the tab so that it can be seen through the slot. Insert the flexible tube which has a non-return valve into the tab. Make sure the valve goes down to the bottom of the tab so that the disinfectant can be used as much as possible.
8. Place the second tab back in the system and insert the flexible tube without a non-return valve. This is your container that will collect the over spraying liquid during disinfection.
9. Close the compartment door and lock with the key.
10. Turn on, the ON / OFF button of the system.
11. Use the other key to open the door at the top rear panel of the system. There is a built-in microphone audio recording and playback button. Press the audio recording button, hold, move closer to the microphone and record your audio message.
12. Press the play button. If you do not like the recording, press the record button again and make a new one. The new entry automatically deletes the old one.

13. Your system is now ready to go. Initially, however, the pipelines will be empty. To bring the disinfectant up to the ultrasonic dispenser and nozzle place your hands in the non-contact chamber several times to activate the sensors. You will hear the sound of the pump but you will not feel any injection. Repeat this action several times until spraying is achieved.
14. If you want to reduce the volume of the audio message this can be done using the button that is built into the audio control panel.
15. If you want to mute the sound completely you can do so using the button that is built into the audio control panel.
16. Enjoy the perfect performance of your ADVA SPS.